

SureStrike™

Laser Training Cartridge



Use the patent pending SureStrike™ Laser Cartridge to train with your own firearm at any location without using live ammo.

SureStrike™ Laser Cartridge is easily inserted into the chamber, and will emit an eye-safe laser pulse, a "shot" of red light, every time the trigger is pulled!

SureStrike™ acts to prevent the accidental loading of a live bullet and with no need to take apart your firearm. You benefit from the full range of dry-fire drills while getting immediate feedback on your performance.

Multi-Caliber Laser cartridge is for an AR15/M4-223, adapters available to fit 9mm, 40S&W, 45ACP, 45LC, 38sp, Shotgun and more.

Multi-Function Convert your kit into a Boresight, Electronic target or simulator activator and more by purchasing additional Action caps.

BE A BETTER SHOT - Spend less effort, time, and money on training!

Includes: SureStrike™ AR15 Laser Cartridge, User guide, 3 reflective targets and battery pack.

Product of Laser Ammo USA Inc.
Phone: 516-858-1262
Made In Israel
www.laser-ammo.com



CAUTION

LASER RADIATION:
avoid eye or skin exposure
to direct or scattered radiation

630nm-660nm, >5 mW
Class 3R Laser Radiation

8 548551 00322 4
223SSLC

Userguide Inside

Laser Training Cartridge for AR15

SureStrike™

Laser Training Cartridge



SAFETY



ACCURACY



FIRING PIN
ACTIVATED



NO VIBRATION
SENSITIVITY

- Marksmanship • Speed • Trigger pull
- Magazine changes • Target acquisition and more...




User Guide

Unload the weapon.

Physically and visually inspect the chamber, bore, and magazine well to ensure that all ammunition has been removed.

Unload ammunition from any magazines that will be used in training. Store ammunition in an area that is separate from your training area.

 Always personally verify that all ammunition has been removed before training.

Do not allow any live ammunition in the training area.

Warning – firearms can cause serious injuries or death.

Unscrew the laser cartridge and insert the battery pack according to the drawing (flat side facing up). Reassemble the laser cartridge carefully. Verify the threading is fully closed and that there is no gap.




Attach the barrel adapter to the front of the Cartridge (see picture).



Retract the bolt and engage the bolt stop in the open position. Make sure the bolt is held firmly by the stop



 Do not continue if the bolt is not held firmly or the bolt stop is not in good working order.



While pointing the barrel down, insert the laser cartridge into the firearm by "dropping" it, barrel adapter first, through receiver (breach) opening into the chamber.



Still pointing down, release the bolt stop. Point the weapon at a safe backstop and pull the trigger to verify that the unit is properly installed and functioning.

Disassembly: Retract the bolt and engage the bolt stop in the open position. Insert a cleaning rod, flat side first, into the barrel and push the Laser Cartridge gently out.



Remove battery when laser cartridge is not in use.

Using the SureStrike Laser Cartridge not according to the user guide will void the warranty.

All firearms are potentially dangerous and can cause a great harm, personal injury and death. It is your responsibility and legal obligation to handle, load, unload, use, transport, maintain and store your firearm in a safe manner.

No liability is expressed or implied for damage or injury as a result of installation or use of this product. Warranty is limited to the replacement or repair of the original product only.

